




1 Download the 'nRF toolbox' app from the Apple app store.




2 Download the firmware file from our website (www.scalextric.com/ARC) on your smart device



3 Click the 'open in' option and select 'copy to nRF toolbox' (This will automatically open the nRF toolbox app)




4 Press 'select file' and 'done'




5

Turn on your Scalextric ARC Powerbase.




6

Press 'Select Device' and choose "Scalextric ARC".




7

Press the 'Upload' button. After some time the connection will drop out and stop. This is putting the powerbase into bootloader mode ready for DFU. The power LED will turn solid orange. Press 'ok' to minimise DFU error message.



8

Select the zip file again.





9

Press 'Select Device' and choose "Scalextric ARC".



10

Press the 'Upload' button again. There should be a progress bar and the download should complete. Ensure the device does not go to sleep halfway through. The power LED will flash green as the firmware transfers



11

You have now updated the BLE chip.

12

You can now check that you are running the updated firmware by connecting the Scalextric ARC App and clicking the 'About' button in the 'Settings' menu.

